

VAST PRO

HIGH PERFORMANCE MOTORIZED GAMING DESK

Manual in English:
Читати українською:



PACKAGE CONTENTS

A) TABLETOP PARTS x2 	B) ADJUSTABLE MOTORIZED TABLE LEG x1 	C) ADJUSTABLE TABLE LEG WITHOUT MOTOR x1 	D) TABLE SUPPORT LEG x2 	E) TABLETOP SUPPORT x2 	F) TABLE CROSSBAR x2 	G) TABLE CROSSBAR CONNECTION SECTOR x1 	H) DRIVE SHAFT x1 	I) SCREW FEET x4 	J) CONTROL MODULE x1
K) CONNECTING BAR x2 	L) POWER UNIT x1 	R) GLASS HOLDER x1 	S) HEADSET HOLDER x1 	U) CABLE MANAGEMENT TRAY x1 	M) HEX KEY x1 	N) SCREW M6 * 12 MM x38 	O) SCREW M4 * 14 MM x2 	P) SCREW M6 * 25 MM x8 	


ASSEMBLY PROCESS

1. Take the sections for the table crossbar (F and G) and connect them. 	2. Using the hex key (M), fasten the structure with screws (N). 	3. Attach the table support leg (D) to the adjustable table legs (B and C) with screws (P). Screw the screw feet (I) into the table supports as shown in the figure. 	4. Fix the table crossbar (F) on the legs with screws (N). 	5. Put the assembled table frame on the floor and fix the tabletop supports (E) on the sides with screws (N). 	11. Connect the power unit (L) as shown in the picture.
6. Install the drive shaft (H) as shown. 	7. Place the two parts of the tabletop (A) face down on a floor and fasten them by using connecting bars (K) and screws (N). 	8. Put the assembled base on the tabletop and fix it with screws (N) as shown in the picture. 	9. Fix the control module (J) in the corner part of the tabletop with screws (O). Fix the cable management tray (U) to the end of the table with screws (N). 	10. Connect the cable to the control module (J). Fix the glass holder (R) and headset holder (S) with screws (N). 	

IMPORTANT TERMS OF USE

1. This table is for its intended use solely.
2. Do not stand on the table or use it as a ladder course it may tip over.
3. Use the product on a horizontal surface.
4. This table is designed for use by one person.
5. Move the table carefully.
6. Do not place the table near heat sources to avoid surface damage and fire.
7. Avoid direct sunlight on the table surface for a long time.
8. It is strictly forbidden to use the table in places with flammable items and in rooms with high humidity.
9. Wipe clean table with a soft dry cloth. Do not use aggressive detergents.
10. Do not allow moisture to get on the power supply.

SAFETY DIAGRAM



WARRANTY AND CARE

LIMITED WARRANTY TERMS

The manufacturer provides a limited warranty on all mechanical assemblies and components of Hator gaming desks for a period of 1 year for Vast Essential tables and 2 years for Vast Pro tables. The warranty is valid if the user observes all precautions and rules for operating the products. The service life of the products is 5 years.

The maximum static load for Vast Essential and Vast Pro tables is 80 kg for each.

Damage of the tables, mechanisms, main units and components due to non-compliance by the user with the rules for using the products outlined in this manual may limit the manufacturer's warranty obligations.

IMPORTANT! The limited warranty does not apply to commercial use of the tables. Commercial use of tables requires agreement with the supplier.

HEALTHY LIVING GUIDELINES

To stay healthy, do not sit continuously. From time to time, but at least once every two hours, get up for 10-15 minutes to walk and stretch. Care about your posture and body position while sitting.

SAFETY USAGE

To ensure safe use, it is recommended to follow the rules below:

- To avoid damaging the table and personal injury, make all table adjustments only when there is nothing on the tabletop.
- To avoid damaging the table and causing an injury, be careful when moving it.
- To avoid tipping over the table, do not rest your weight on one edge of the tabletop.
- To prevent burning of the surface, cracking of plastic components, do not expose the table to strong heat, for example, from a radiator or fireplace. Protect the table from direct sunlight.
- To avoid damaging, do not exceed the maximum load weight on the table.

Tables are designed for use in standard temperature conditions.

CARE AND CLEANING

There are minimal requirements for keeping up the table. In case of loosening of individual parts of the table, please tighten the loosened bolts. When the table becomes dirty, clean up with a slightly damp cloth and suitable cleaning agents. Do not use bleach or aggressive cleaning agents. It is recommended to clean up the tabletop periodically, but at least once a month.

Choose a gaming chair:

